


Virtual Trainer



MultiSport v1.0 **USER MANUAL**





MultiSport v1.0 **USER MANUAL**

Index

1.0	Introduction	2
1.1	What is Virtual Trainer Multisport.....	2
1.2	Who is the Virtual Trainer Multisport user.....	2
2.0	Package description and installation.....	3
3.0	SmartPad connection.....	4
4.0	Virtual Trainer Multisport Operation by SmartPad APP.....	5
4.1	Setting the VTM.....	6
4.1.1	Color and Buzzer.....	6
4.1.2	Time, Distance and Reps.....	6
4.1.3	Saving and loading data.....	6
4.1.4	MODE selection.....	7
5.0	MODEs description.....	8
5.1	RUN mode.....	8
5.2	Speed mode.....	8
5.3	Elastic mode.....	9
5.4	Jump mode.....	10
6.0	Running VTM workout.....	10
6.1	VTM workout sequence.....	10
6.2	VTM workout sequence Stop/Pause.....	11
7.0	Troubleshooting.....	12
7.1	Warnings on SmartPad Message Area	13
7.2	Warnings on Strip	14
8.0	Suggested workouts.....	15
8.1	Training your reactivity	15
8.2	Strengthening drill	15
8.3	Reference timing	15
9.0	Optional MODEs.....	16
9.1	Sprint stride	16
9.2	Jump random.....	17



MultiSport v1.0 **USER MANUAL**

1.0 Introduction

This manual refers to the **version v1.0** of the **Virtual Trainer Multisport package** here simply called Virtual Trainer Multisport or VTM.

1.1 What is Virtual Trainer Multisport

Virtual Trainer Multisport is your training mate, the best aid to improve your athletic performance in sprint disciplines. The **LED light** reference, you have to follow, acts as a pacemaker.

Elite sprinters have such a great acceleration that after 30 meters their speed is already 12 m/s. Of course, the acceleration of a regular sprinter is a little lower. By its mathematical model VTM allows you to simulate speed progression of any sprinter from beginner to elite athlete.

The VTM main mode impose the **LED light** to cover the distance you have chosen in the desired time, following an adjustable built in acceleration curve. This curve has been obtained by statistical analysis of data related to a significant number of races performed by both elite and regular sprinters.

The two additional modes available on VTM are jump/stride and elastic. The former allows to improve the stride length or frequency. By this function you can set the distance among a series of **LED light spots** so you have a reference where the feet have to touch the ground. The latter provides a **LED light** moving back and forward alternatively. By this function, that can be randomly set, the reaction to direction changes can be effectively trained.

1.2 Who is the Virtual Trainer Multisport user

Virtual Trainer Multisport has been designed to provide an aid to those disciplines where sprint and run performances are crucial. From Track and Field to Soccer and Baseball the train improvements gained running behind a **LED light** spot that pulls you at your desired speed, acceleration and direction are remarkable. Jumping from a point to another driven by the **LED light** spot, set at the chosen distance, helps the athletes to become faster and more powerful. Thus, VTM is advisable in team sports where running speed plays an important rule like American football, Basket and Rugby. No matter the degree of workout you can develop, VTM can be set at different levels of difficulty just changing the basic setting.

VTM comes with preloaded setting easily to be uploaded that will satisfy both the amateur and professional athlete.

Virtual Trainer



MultiSport v1.0 **USER MANUAL**

2.0 Package description and installation

Virtual Trainer Multisport V1.0 package comes with the **Handbag** (A) (dimensions about 300 mm width - 250 mm high - 150 mm deep) , the **SmartPad** (B) (119 x190 mm) and the **LED Strip** (C) in a Coil.



The embedded **microprocessor unit** that drives the LED strip is fed by 12 V internal battery. The SmartPad is hold on the Handbag and is removable, being operated at the longest distance of about 15 meters.

On the Handbag internal cover side the **USB SmartPad Charger** (H1) and the internal **12V battery Charger** (H2) are available.



The internal 12V battery Charger must be connected to the **socket** (D) in order to recharge the system. The **Pushbutton** (E) allows to switch ON and OFF the system. It must be switched ON while the internal 12V battery is under charge. The VTM can be operated even with the charger powered.

Once the **LED Strip** (C) is positioned on the track field (or wherever) as desired it has to be connected to the **socket** (F) by its own plug.

As soon as the **LED Strip** is connected to the socket (F) and the VTM is switched ON by the pushbutton (E) the whole **LED strip** is lighted. Then, VTM is ready to be operated.



MultiSport v1.0 **USER MANUAL**

When the 12V internal battery is charged the led on its Charger (H2) turns **green**. While charging its light is **red**. The charge status of the 12V internal battery is shown on the SmartPad (B).

Once the battery is charged you can enjoy VTM, free of any wiring to electric power, all day long. Charger plugs type are according to European standard. Therefore, a power adapting device is needed if VTM is operated in countries with different standard.

The **Handbag** is water proof when it is kept closed only. When its cover is opened, water dropping in can damage the system. Hence, when VTM Handbag is placed open air it must be protected from rain. Conversely, the **LED strip** provides water protection degree IP68, so it can be operated open air under rain condition.

In case of LED strip length longer than 25 meters an **auxiliary 12 V battery supply** is required to be applied on the end side of the LED strip. This auxiliary device is provided on the Handbag cover. So, connect it to the end of LED strip and switch it ON.

NEXT STEP IS TO CONNECT YOUR SMARTPAD as described in next chapter 3.

3.0 SmartPad connection

- 1 Once the 12V internal battery is charged, switch the system ON by its pushbutton.
- 2 Switch ON your **SmartPad**. Then, select **Setting / Wireless & Network** and verify VIRTUAL TRAINER network connection. If not connected, do establish connection manually, no password is required. Do not forget to stand in the range of 15 meters from Handbag.
- 3 Just select the web browser and automatically you will get the **Virtual Trainer Multisport application** running. If not, you can manually start the VTM application by typing on the browser the address: <http://10.10.10.1/sd/tef13/index.php>.

NOTE: VTM is addressable and controllable by your own pad or smartphone as well, just typing the above mentioned address in the browser. After a few seconds the symbol on top left corner of the **VTM application in the SmartPad** will turn from not connected to connected status. Now you can enjoy your Virtual Trainer Multisport.

VTM application not connected



VTM application connected




NEXT STEP IS TO ENJOY YOUR **VTM** BY OPERATING THE APP as described in next chapter 4.

Virtual Trainer



MultiSport v1.0 **USER MANUAL**

4.0 Virtual Trainer Multisport operation by SmartPad APP



1 = Sequence Start button

2 = Connection status indication

3 = Message Area

4 = Load/Save/Delete button to deal with file

5 = Sequence Pause button

6 = File name select window

7 = Battery charge status indicator

8 = Time to run setting

9 = Number of repeats setting

10 = MODE selection

11 = Sequence stop button

12 = Buzzer enable/disable

13 = Strip Color selection

14 = Distance to run setting

15 = Number of actual repeat

16 = Rest time setting



MultiSport v1.0 **USER MANUAL**

To operate the VTM by SmartPAD APP you just have to set up the system. You can do that by loading a previously saved setting or by direct inserting data. The last setting is kept by the system.

4.1 Setting the VTM

Configuring your **Virtual Trainer MultiSport** application permits you to exploit its performances and enjoying the wide range of different workouts that can be carried out.

4.1.1 Color and Buzzer

Select the desired **LED strip** color by (13) (green, red or blue). Choose whether or not working with Buzzer by (12).

4.1.2 Time, Distance and Reps

Set the actual **DISTANCE** that the **LED light** must cover by (14). Admitted values are between **5** and **100** meters (resolution is 1 meter). Set the **TIME** to run such a distance by (8). Admitted values are between **1** and **30** seconds (resolution of hundredths of seconds).

Set the **Number of Repeats** you want to carry out by (9), admitted values are between 1 and 100, and the **REST TIME** between two repetitions by (16). This time can be set between 0.10 and 1200 seconds (resolution of hundredths of seconds).

If the couple of values relevant to **DISTANCE** and **TIME** are chosen in nonsense way, i.e. 100 meters in 1 seconds, then “time too short” message will appear in the Message Area (3).

4.1.3 Saving and loading data

The button Save (4) allows to store all data in a .txt file. The application asks to define a name for the actual setting to be saved. If an existing name is entered, the old file will be overwritten without warning. Data can be recovered by the button Load (4). In this case, the file name must be selected by (6). The existing files can be deleted by button Delete (4).

All data of the **VTM** application are stored in the .txt file with the only exception of the Buzzer selection.




MultiSport v1.0 **USER MANUAL**

4.1.4 MODE selection

The **VTM** application version 1.0 can be configured in the following modes:

RUN: the **LED light spot** is moving according to the defined acceleration rate (adjustable) in order to run the desired **DISTANCE** (14) in the set **TIME** (8). Then, the system will wait the **Rest Time** (16) and will start again a **Number of repeats** (9) times. The rest time is defined as the period when the athlete takes a breath between repetitions. Then, the LED strip shows the elapsed rest time as described in chapter 5.1 step 3.



ELASTIC 1: the **LED light spot** is moving back and forward to cover the **DISTANCE** (14) in the set **TIME** (8). Each path can be set as acceleration stroke, deceleration stroke and waiting time before reversing speed. The number of times this jogging is performed is defined by the **Number of repeats** (9) parameter.

ELASTIC 2: this mode is similar to ELASTIC 1 with the only difference that last point of the running path is chosen by the microprocessor in a random way. This last point is calculated to be placed between the start point and the set **DISTANCE** (14).

ELASTIC 3: this mode is similar to ELASTIC 2 with the only difference that the start point of the **LED light spot** becomes not fixed as well. The start point position is calculated by the microprocessor in a random way (as the last point).

JUMP: a series of fix **LED light spots** is lighted from the start position to the set **DISTANCE** (14). The distance among these spots is defined by the user.

If a value out of range is inserted in the data input field, the error message: "**WRONG DATA**" will appear in the Message Area (3). In this case the system will set a default value in place of the wrong one. Message Area (3) is written when VTM run is started by (1).




MultiSport v1.0 **USER MANUAL**

5.0 MODEs description

5.1 RUN mode

RUN mode moves the **LED light spot** according to a speed curve as shown in the picture. The speed is raised by a mathematical model from zero to its maximum value. This value is calculated in such a way to run the defined **DISTANCE** (14) in the desired **TIME** (8). The rising speed curve has been defined




by a mathematical model that takes into account the average behavior of several real cases taken from data performances of both top rank and average athletes. This curve can be trimmed by the user just changing the parameter “**Acceleration Adjust**” by (18). The range of this parameter is from 80% to 120 % with resolution of units. By the “**Acceleration Adjust**” the athlete can test different slopes of speed ramp up curve. 120% is the fastest increase of speed (acceleration).

The parameter “**Reaction Time**” can be set by (17) between 0 and 3 seconds with resolution of thousandths of seconds. The “**Reaction Time**” is here defined as the elapsed time from the start signal to the instant when the athlete starts to actually move. Of course its regular value is around 0.15 seconds.

If VTM calculation algorithm fails, when RUN mode, mainly due to incoherent data entered, a constant **red LED light spot** appears on the strip at a distance of 500 mm from the starting point.

5.2 SPEED mode

SPEED mode moves the **LED light spots** at a constant speed. This function, otherwise called Constant Speed, is very useful to train your maximum speed in the right relaxed way. Usually you do not know your actual speed while running even though it is important to be aware of your rapidity, especially in 200 and 400 meters sprint. You can set your VTM at the speed you would like to





MultiSport v1.0 **USER MANUAL**


reach (i.e. 10.0 m/s) and a **LED light** by its multiple moving spots will provide you the reference to follow. Every moving spot is positioned at the defined distance [22] away from the spot ahead and behind so the runner can easily catch the closest to him. The lasting time of this spots movement is set by [23]. Repeats are not applied to this mode.

5.3 Elastic mode

ELASTIC 1 mode moves the **LED light spot** according to a curve composed by an acceleration stroke, a constant speed phase and a deceleration stroke. The acceleration and deceleration strokes are set as a percentage of the total **DISTANCE** by the parameters “**Acc.Dist.**” (21) and “**Dec.Dist.**” (20) respectively. The admitted range of the former is from 1 to 50 % while the range of the latter is from 1 to 33%. Their resolution is unit of percentage. Then, VTM calculates the constant speed value needed to run the defined **DISTANCE** (14) in the desired **TIME** (8) according to speed curve showed in the next picture.

The parameter “**Rev.Time**” (19) is related to the reversing time. It is the time to wait, at the end of deceleration stroke, before changing the speed direction. The range of this parameter is from 0 to 10 seconds with resolution of hundredths of seconds.

When **ELASTIC 2** mode is selected the microprocessor takes the actual **DISTANCE** to run in a **random way** and in any case not greater than **DISTANCE** (14). Instead, the starting point is kept steady. On the contrary when **ELASTIC 3** mode is selected the starting point is left randomly floating as well.



When any of the **ELASTIC** modes is selected and VTM calculation algorithm fails, mainly if incoherent data are entered, a constant **red LED light spot** appears on the strip at a distance of 800 mm from the starting point.


The number of times the LED light is moved back and forward is defined by **Number of repeats** (9).



MultiSport v1.0 **USER MANUAL**

5.4 Jump mode

When **JUMP** mode is selected a series of equidistant **fix LED light spot** is lighted from the start position to the set **DISTANCE** (14). The distance among these spots is defined by the parameter “spots distance” (22). The admitted range is from 0.5 to 10 meters and its resolution is hundredths of meter.



6.0 Running VTM workout

Once the VTM configuration is done as described in the above chapters you can enjoy your workout just pushing the **START** button (1) of the SmartPad APP.

If no mode is selected by the window (10) the message: “**Mode selection required**” will appear on the Message Area (3).

6.1 VTM workout Sequence

First of all, by icon (2), you have to check that SmartPad connection with the embedded microprocessor (resident on Handbag) is established. If not, follow the steps described in chapter 3 (SmartPad connection). Be sure of the right status of the 12V internal battery by (7), green is ok. If not, charge it as described in chapter 2 (package description and installation).

Just **PRESS** the **START** Button (1) to start your workout sequence.



Once that **START** button (1) in the SmartPad is pressed, the message: “**DATA requested**” appears in the “**Message Area**” (3). This means that the VTM application is sending data to the LED strip driving microprocessor.

After a few seconds this message is replaced with “**DATA PROCESSING**”. This means that microprocessor is correctly driving the LED strip.

1 First step: the **Starting procedure** is started, regardless the selected **MODE**.

Starting procedure:



MultiSport v1.0 **USER MANUAL**

- A red **LED light spot** is lighted for 1 second at the start position. This is the “**on your marks**” warning signal. Then, **LED light spot** is switched off.
- After 1 second the same red **LED light spot** is lighted for 1 second. This is the “**SET**” signal. Then, **LED light spot** is switched off.
- After a random time between 2 and 3 seconds the same red **LED light spot** is lighted for 1 second. At the same time the running **LED light spot** is started. This is the actual “**Shot**” signal.

If the buzzer is selected ON by (12) at the red **LED light spot** a bip sound is associated.

2 Second step: the LED lighting is activated according to the selected MODE.

3 Third step: the system waits the defined **Rest Time** (16). During this time interval a light blue **LED light spot** line will move back from the end of the strip **DISTANCE** toward the starting position at regular speed. By this, the athlete is able to figure out the remaining time to next start. The actual repetition number is shown by (15).

- This step 3 does not apply to ELASTIC, JUMP and SPEED modes -

Fourth step: the whole sequence is repeated until the **Number of repeats** (9) is accomplished.

4 - This step 4 does not apply to JUMP mode and SPEED mode -

6.2 VTM workout Sequence Stop-Pause

While the **LED light spot** is moving on strip, the “**DATA PROCESSING**” message is active and the SmartPad does not communicate with the LED driving microprocessor. ~~(1)~~

This means that it is not possible to interrupt the VTM sequence via SmartPad command. If it is necessary, the sequence can be interrupted by switching OFF and ON the system.

On the contrary, during **Rest Time** (16) period the system is put in communication ⁽¹⁾ again and VTM sequence can be stopped by the button **STOP** (11) on the SmartPad APP.



MultiSport v1.0 **USER MANUAL**


Alternatively, during **Rest Time** (16), the sequence can be paused by the button **Pause** (11) on the SmartPad APP. This request can be selected at any moment but it becomes active in the resting time period only. If neither the Stop nor the Pause buttons are selected the sequence goes on until the **Number of repeats** (9) are accomplished. Then, the system is ready for a new possible parametrization or a new workout sequence start.

7.0 Troubleshooting

	PROBLEM	SOLUTION	NOTE
1	The LED Strip do not get lighted.	<ol style="list-style-type: none"> 1. Check whether the strip is well connected to the socket (F) 2. Check that the system 12V internal battery is charged 3. Switch OFF and ON the system pushbutton (E) 	If one LED of the strip gets damage, the strip from that point on will not work.
2	Cannot find VIRTUAL TRAINER wifi	<ol style="list-style-type: none"> 1. Check that the 12V internal battery is charged 2. Switch OFF and ON the system pushbutton (E) 3. Restart the SmartPad 4. Verify the SmartPad is in the range of 15 meters 	VIRTUAL TRAINER network will appear on our SmartPad when the system is correctly working



MultiSport v1.0 **USER MANUAL**

3	Cannot connect VIRTUAL TRAINER multisport APP 	<ol style="list-style-type: none"> 1. Check that the 12V internal battery is charged 2. Switch OFF and ON the system pushbutton (E) 3. Verify the SmartPad is in the range of 15 meters 	
4	The internally battery do not get charged.	<ol style="list-style-type: none"> 1. Check whether the charger is plugged in (D) and its light is red (charging) 2. Check that the system is switched ON (E) 	The system must be switched ON (E) when charging battery
5	When the Led strip is connected plugged in (D) and system is switched ON (E) the LEDs do not get lighted	If the internal battery is charged. You have a problem.	Contact your supplier

7.1 Warnings on SmartPad Message Area

“DATA requested”

means that VTM APP, that is running on SmartPad, sent the data request to the LED strip driving microprocessor (placed on the Handbag). If this message stays hold, it means that the microprocessor is not running correctly and do not gets data from the VTM application. Check the SmartPad distance from the control unit (<15meters) and the correct status of battery charge.

“DATA PROCESSING”

means that VTM is correctly driving the LED Strip. This message appears just after the “DATA requested” message and means that microprocessor has received data. When this message is active the



MultiSport v1.0 **USER MANUAL**

communication between the microprocessor and the VTM application on SmartPad is correctly not active.

If this message is issued and the LED strip do not get lighted the system is faulty or badly connected.

“Mode selection required” means that no MODE (10) is selected. System holds waiting for mode selection.

“time too short” means that DISTANCE (14) and TIME (8) are not coherent and the speed would be too high. System holds waiting for new data.

“WRONG DATA” means that DATA are not coherent. i.e a character instead of a number is entered. System holds waiting for new data.

“wrong data:” wrong data message followed by description warns the user about the wrong values entered and sets the default number. System holds waiting for new data.

“System reset required” when this message appears the system is in a dead lock. It must be reset by switching OFF and ON the main pushbutton (E).

The messages issued on “Message Area” (3) are overwritten. So, only the last one is visible.

7.2 Warnings on Strip

1. **Red LED light spot on Strip** at a distance of **500 mm** from the starting point: error in the **RUN** mode algorithm. Change of parameters needed.
2. **Red LED light spot on Strip** at a distance of **800 mm** from the starting point: error in the **ELASTIC** mode algorithm. Change the parameters needed.



MultiSport v1.0 **USER MANUAL**

8.0 Suggested workouts

Let's assume that your personal best in 60 meters is 7.05 seconds and that you want to make a consistent speed training 12 x 60 meters at the 95% of your personal best (7.43). Just set your VTM in **RUN** mode, then input **DISTANCE** (14) equal to 60 and **TIME** (8) equal to 7.43 seconds. Then, set **Number of repeats** (9) equal to 12 and choose **Rest Time** (16) as desired. Now you can enjoy the "pulling effect" and the pace function provided by VTM.

8.1 Training your reactivity

VTM is the ideal tool to train your starting phase of 100 and 200 meters race. Workouts focused on improvements of reactivity and power progression along the first 30 meters can really bring you to next level. Set your VTM in **RUN** mode, input 20 meters as **DISTANCE** (14) and **TIME** (8) equal to 3.0 seconds. Make 10 repetitions by setting **Number of repeats** (9) to 10 and carry out your resting time between repetition, i.e. **Rest Time** (16) equal to 80 seconds. Repeat this sequence decreasing the time until you reach 2.8 seconds. Just run avoiding great bounds that force your legs but keep thoughtfulness on reacting time and on the "pulling effect" coming from the **LED light**. This helps you in becoming very quickly in starting phase.

8.2 Strengthening drill

As well known, the stride in flight phase is calculated just multiplying the trochanter height by 2.3 for men or 2.2 for women. Set the VTM in **JUMP** mode and input the **Spot Distance** (22) according to this rule taking into account your physical data. Then, you can strengthening your legs by both drilling multiple bounds at huge stride and by plyometric workouts done with one or two legs.

The further advantage provided by VTM **LED light spot** reference consists on the quick spots setting. This allows you to easily test different spot distances. Do not forget that a very strong correlation occurs between multiple bounds distance and final 100 meters race time.

8.3 Reference timing

As your reference the following table reports the 100 meter race timing of the historical world champion athletes. You can set your VTM according to these figures and try to follow the **LED light**. Good luck.



MultiSport v1.0 **USER MANUAL**

DISTANCE [m]	Usain Bolt Berlin 9,58 s WC 2009 [sec]	Ben Johnson Seoul 9,79 s OG 1988 [sec]
0	0	0
0 [RT]	0,146	0,132
10		1,83
20	2,89	2,87
30		3,8
40	4,64	4,66
50	5,475	5,5
60	6,31	6,33
70		7,17
80	7,92	8,02
90		8,89
100	9,58	9,79

9.0 Optional MODEs

These optional mode are not available on *VTM v1.0*. They can be supplied upon request.

9.1 Sprint stride

The function **Sprint stride**, otherwise called Ground Contact, provides a series of fix **LED light** spots reference with the purpose to show the position where feet must contact the ground during run. VTM offers you a model based algorithm that places the **LED light** spots along the strip according a statistical analysis founded on both top rank and regular athletes data. Assuming that you want to run 60 meters in 7.14 seconds, before starting you will see all the spots of your ideal stride. After start every spot will change color from the first one to the last one according to the time pacing defined by yourself. Additionally, if the athlete places a camera by side he really sees where his mistakes are.



MultiSport v1.0 **USER MANUAL**

9.2 Jump random

The function **JUMP random** refers to the Jump mode included in the VTM v1.0. But in this case only one **LED light spot** is switched on. Then, the closest spots either toward right or toward left will be switched on in random way following the time defined by the athlete. This function allows to practice promptness in reacting and strength when changing direction.